

1-D thermal wave imaging

Periodic thermal excitation gives rise to a periodic temperature field throughout the sample. The classical thermal wave method for thermal diffusivity measurements is based on a simple dispersion relation for harmonic heat diffusion in one dimension in a homogeneous isotropic solid. In these expressions, κ is the thermal diffusivity, ω and q are the angular frequency and wave number.


$$Q = Q_0 \sin(\omega t)$$

(laser heating)

$$T \sim e^{(iqx - i\omega t)}$$


$$q^2 = i\omega / \kappa$$


$$\Delta\theta = \text{Re}(qx) = \sqrt{\omega / 2\kappa} \Delta x$$




3-D thermal wave imaging


Homogeneous isotropic material ($\kappa_1 = \kappa_2 = \kappa_3 = \kappa$)

$$\kappa_1 x_1^2 + \kappa_2 x_2^2 = 1$$





Homogeneous anisotropic material ($\kappa_1 \neq \kappa_2 = \kappa_3$)

$$\kappa_1 x_1^2 + \kappa_2 x_2^2 = 1$$





Thermal Wave Imaging: Experiment

Experimental setup



Sensing small ΔT



- Small temperature induced changes in optical reflectivity are measured with the aid of a lockin amplifier
- Typically, the phase output of the lockin is analyzed because this quantity is insensitive to variations in background reflectivity


Sample specification

- 200 nm polycrystalline chromium film (thermally isotropic)
- Single crystal quartz substrate (trigonal symmetry)
- C-axis coincides with x_1 axis and hexagonal edge coincides with x_2 axis

$$K = \begin{vmatrix} K_{11} & & \\ & K_{22} & K_{23} \\ & K_{32} & K_{33} \end{vmatrix}$$

Thermal Wave Imaging Application: Thermal Anisotropy

Phase contour



Phase contour reveals thermally anisotropic nature of substrate for kilohertz range modulation

Observations

Lateral resolution is related to the optical spot size ($\sim 1\mu\text{m}$).

Depth resolution is related to thermal constants and modulation frequency (1 MHz \rightarrow 100nm for chromium film/single crystal quartz substrate).


A good fit to the data was obtained by setting contact resistance to zero.

Observations

The phase contour exhibits symmetry about the x_1 and x_2 axes. For second rank tensor properties the symmetry exhibited by trigonal systems cannot be distinguished from hexagonal systems.

The anisotropic nature of this problem imposes a restraint on choosing the contact resistance. Namely the theory should correctly predict the difference in slope of the phase lag along the x_1 and x_2 directions.

Phase profile



The profile shows conjugate relationship between changes in position and changes in frequency